

CAMERA SENSORS AND CONTROL

Chris Wood


Overview

- What is an Image?
- Camera sensors
- Quantum Efficiency
- What is bit depth?
- Noise and Signal to Noise
- What is resolution?
- What are you resolving?
- Camera control parameters

What is an Image?

- Since computers store data and understand data in a numerical form, we can say that an image is a numerical representation of a “picture” – a set of numbers interpreted by the computer which creates a visual representation that is understood by humans
- The images we will be dealing with are generated from what instruments termed
 - CCD (Charge Coupled Device)
 - CMOS (Complementary Metal Oxide Sensor)
 - Laser Scanning Confocal microscopes.
- A charged coupled device is made from a modified piece of silicon which has an array of wells of a known size, which we refer to as pixels.

What is an image?




This.....

168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168
168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168
168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168
168	168	168	168	168	168	109	107	168	168	168	168	168	168	168	168	168	168	168	168
168	168	168	168	168	111	111	110	111	168	168	168	168	168	168	168	168	168	168	168
168	168	168	168	168	168	112	109	168	168	168	168	168	168	168	168	168	168	168	168
168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168
168	168	168	168	168	168	168	168	168	168	109	109	110	111	168	168	168	168	168	168
168	168	168	168	168	168	168	168	168	168	110	112	112	112	112	114	168	168	168	168
168	168	168	168	168	168	168	168	168	168	109	109	111	111	109	112	168	168	168	168
168	168	168	168	168	168	168	168	168	168	168	109	111	111	109	168	168	168	168	168
168	168	168	168	168	168	110	110	112	112	168	168	168	168	168	168	168	168	168	168
168	168	168	168	168	168	108	109	109	111	112	112	168	168	168	168	168	168	168	168
168	168	168	168	168	168	109	111	112	112	111	168	168	168	168	168	168	168	168	168
168	168	168	168	168	168	109	110	111	111	168	168	168	168	168	168	168	168	168	168
168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168
168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168
168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168
168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168	168

Is really this

Think like the computer – The Bitmap

- The Bitmap is the information the computer uses to form the image, each pixel can be seen in its XY position and with its corresponding greyscale value.
- Remember the image is these values interpreted by your eyes




The screenshot shows a software window titled "Bitmap Analysis" with a menu bar containing "File", "Options", and "Update". Below the menu is a table with 8 rows and 5 columns. The first column is labeled "Pixel" and contains indices 0 through 7. The next four columns contain greyscale values for each pixel. The table is surrounded by standard window controls and a scrollbar.

Pixel	0	1	2	3
0	174	174	174	174
1	173	173	173	171
2	172	172	172	171
3	172	171	171	170
4	173	172	172	172
5	172	174	175	175
6	170	171	174	175
7	170	173	175	175



The Histogram

- The Histogram is a graphical representation of the distribution of greyscales within an image
- This acts as a description of the image and we can clearly see the dark spots and the grey background
- We can use this information to make measurements based on greyscale



The Line Profile

- The Line Profile is a great exploratory tool for looking at discrete regions within an image
- When we select the tool, a line appears on the image which we can move and grow
- This gives us the greyscale information along the line
- By selecting to view either a thick vertical or thick horizontal line we can see how flat our image is and so see whether we need to account for this before we do any processing



Bit Depth

- Depending on the camera used, each pixel can carry from 1 to 32-bits.
- For a normal 8-bit monochrome camera each pixel has a possible 256 grey scale values.

- Black = 0

- White = 255


- For a 12-bit monochrome camera each pixel has a possible 4096 grey scale values

- Black = 0

- White = 4095

Bit Depth and Grey Scale



- The Human eye can accurately detect around 40-60 grey levels
- 8-Bit cameras detect 256 grey levels; each grey level captured will be accurately repeated by the monitor display
- 12-bit cameras generate 12-bit images; these contain 4096 grey levels
- The 12-bit scale gives far greater ability to capture the Dynamic range. This allows you to extract your data from a larger range



8-bit versus 12-bit



- Of the two images shown opposite, the top one was taken with a regular 8-bit video camera and the bottom one with a 12-bit Scientific Grade CCD camera

- When the greyscales are matched for the monitor we can see very little difference between them




8-bit versus 12-bit

- On closer investigation of the darker regions - by effectively zooming into the brightness - we can see that the 12-bit image holds far more information
- We can achieve this by altering the Display Range (section 2)
- Capturing a greater range of greyscales gives higher intensity



Auto Scaling

- As we live in an 8-bit world with 12, 14 and 16-bit image files we often have to scale images to make them visible
- Example: low light but 100 electrons of signal will give me reasonable data using a 14-bit camera.
- With 14-bits my camera assigns 1e/1grey level meaning my image will have 100 grey levels (+ the offset) of greyscales which will be visible in an image with 65535, so unless we scale the image we will not see the data




Sensor Types

- CCD – Charge Coupled Devices
- EMCCD – Electron Multiplied CCD
- CMOS - Complimentary Metal Oxide Semiconductor


CCD Fundamentals

The Charge-Coupled Device (CCD)


- Invented in 1970 at Bell Labs
- A silicon chip that converts an image to an electrical signal
- Image is focused directly onto the silicon chip
- Widely used in TV cameras and consumer camcorders
- Special high-performance CCDs made by:
 - Eastman Kodak (Rochester, NY)
 - Thomson CSF (France)
 - Marconi (formerly EEV — England)
 - SITe (Beaverton, OR)
 - Sony
 - Others



CCD Fundamentals




CCD Fundamentals




Array of Discrete Photodetectors

CCD Fundamentals




CCD Operation
Integration of Photo-Induced Charge

CCD Fundamentals




*CCD Operation
Parallel Shift - 1 Row*


CCD Fundamentals




CCD Fundamentals




CCD Fundamentals




CCD Fundamentals




CCD Fundamentals




CCD Fundamentals




CCD Fundamentals




CCD Fundamentals




CCD Fundamentals









CCD Fundamentals



CCD Fundamentals



CCD Fundamentals



Full Frame

Frame Transfer
(EMCCD)

Interline Transfer

Sensitivity


- Sensitivity is a horrible word which is often confused with Quantum Efficiency, Pixel Size, Signal and Signal to Noise.

We do know some key facts:


- Photons convert to electrons in sensors and they can then be measured – this conversion rate is defined as Quantum Efficiency
- Sensors convert photons of some wavelengths better than others
- The number of photons that interact with our pixel will depend on the physical size of the pixel
- We can have a sensitive sensor but if our signal to noise is low we get a noisy image with data we cannot decipher

What is Quantum Efficiency?

- Quantum efficiency (QE) is a measure of the effectiveness of an imager to produce electronic charge from incident photons.
- In the high-purity crystalline form, each atom of silicon is covalently bonded to its neighbour. Energy greater than the band gap energy, about 1.1 eV, is required to break a bond and create an electron/hole pair.
- The wavelength of incoming light and photon absorption depth are directly related; the shorter the wavelength, the shorter the penetration depth into the silicon.
- Light normally enters the CCD through gates of the parallel register (front-illuminated CCD). These gates are made of very thin polysilicon, which is reasonably transparent at long wavelengths, but becomes opaque at wavelengths shorter than 400 nm. Thus, at short wavelengths, gate structure attenuates incoming light.




QE Curves




- Spectral response curves are often shown on camera specification sheets.
- Some manufacturers claim higher responses than are achievable, but note these often vary from sensor to sensor
- Some manufacturers will also quote a relative response from 0 to 1
- The battle for good QE is fought in the flatness, max peak and responses to red dyes such as Cy5 (670nm)
- A QICAM is not suitable at this part of the spectrum as QE is only 5% at 670nm

Front and Back illumination

- Some cameras are back thinned and back illuminated to be as efficient as possible with incoming light
- Typical front illuminated QE 40-60% at Lambda Max
- Typical Back illuminated QE 90% at Lambda Max



What is actually happening at each Pixel?




What's happening

1. Photon hits the CCD sensor
2. Photon is then converted to an Electron
3. Electron is then digitised using an Analogue to Digital converter (ADC)
4. Electron value is now converted to a grey scale
5. User measures grey scale (ADU)

Note - The camera is completely in control over grey scale values and changing camera parameters doesn't change the light detected.

Reconstructing the Image

- The image is generated by the reconstruction of the well information (now digitized into grayscale values) into the image pixels.
- Pixels are identified by their position in a grid (two-dimensional array), referenced by its row (x), and column (y).





Noise Overview

- Living with Noise
- What is Noise
- Noise sources
- Signal to Noise equations
- Telling signals apart

Living with Noise

Noise exists on every camera and in every measurement



Dependent on the image scale used you may or may not see it.

Why do we see noise ?

- We normally see noise when the signal we have is low in comparison to our required exposure

Reasons for trying to get a short exposure:


- Need to monitor at high speed
- Need to minimise sample damage
- Need to focus at live rate

Measurement Uncertainty


- If you measure a signal of 100 electrons in one pixel and 102 in another, are they different values?
- Noise distorts measurements and increases the uncertainty in measurements.

Image Quality

Although images are purely data you can't avoid the pretty picture club



Low Gain – Long Exposure – Low
Noise




Higher Gain – Short Exposure – More
Visible Noise

Noise Sources

- CCD systems suffer from 3 types of noise:
 1. **Dark Current** – noise from heat and cosmic noise - exposure dependent
 2. **Read Noise** – noise of reading the signal - fixed
 3. **Photon Shot** – square root of signal - signal dependent

Read Noise

- Minimized by careful electronic design
- Under low-light/low-signal conditions where read noise exceeds photon noise, data is read noise limited
- Read noise is not as significant in high-signal applications
- Read noise = $\text{std}^* \text{system gain}^* 0.707$
(std of subtracted bias images)



Reading all the buckets - what's
my Error?

Dark Current

- Dark Current is created by heat and cosmic noise and can be reduced by cooling
- Dark Current builds over time unlike read noise
- Dark current reduction is sensor dependent
- For example, some sensors will halve dark current for every 7 degrees of cooling; some require more cooling
- Other technologies can be applied which reduce the cooling required

Retiga SRV (cooled to -30) Dark Current 0.15 e/p/s

Exi Blue (cooled to zero) Dark Current 0.005 e/p/s

Photon Shot Noise

- Law of physics
- Square root relationship between signal and noise
- Noise = square root of number of electrons
- Poisson distribution
- When photon noise exceeds system noise, data is photon (shot) noise limited

Signal to Noise

- Standard CCD SNR Equation:

$$\bullet \text{SNR} = [S * QE] \div \sqrt{[S * QE^2 + D + \sigma_R^2]}$$

- S = Signal in Photons (converted to electrons by * QE)
- QE = Quantum Efficiency of light at that emission
- D = Dark Current Noise = Dark Current * Exposure Squared
- σ_R = Read Noise
- All values must be compared in electrons

Signal to Noise Calculators

- Many Signal to Noise calculators exist but a quick and easy one to use is at www.photomet.com - Select scientific imaging tools
- Simply enter your gain, signal, read noise, dark current and exposure time
- A good experiment is to see how varying dark from 2 to 0.001 effects a 100ms exposure

Signal to Noise Calculator

The image shows a screenshot of a web-based calculator interface for Photometrics. The interface is dark-themed with white text and input fields. At the top, the Photometrics logo is displayed. Below it, the title 'Signal to Noise Calculator' is shown. The calculator has several input fields for user-defined parameters and several output fields showing calculated results. The inputs include e-/ADU, Signal (grey values), Read Noise, Dark Current, and Exposure time (seconds). The outputs include Signal in Electrons, Dark Current Noise, Total Noise, Signal to Noise Ratio, and Noise in Grey Scale Values. A 'CALCULATE' button is located at the bottom right of the calculator area.


e-/ADU:	1
Signal (grey values):	2000
Read Noise:	5
Dark Current:	0.1
Exposure time (seconds):	0.1
Signal in Electrons:	2000
Dark Current Noise:	0.01
Total Noise:	45
Signal to Noise Ratio:	44.44
Noise in Grey Scale Values:	45

CALCULATE

Input fields in white, hit calculate!

Measurement Confidence

- If we have 2 pixels next to each other - one has a value of 30 and the other 20, we will assume noise is 5 electrons
- Q, Can we tell them apart?
- A, No – the error bars overlap and so we have no confidence in the measurement
- The signal change that can be detected with confidence is calculated using a confidence level calculation



Confidence Level Equations

*$(\text{Inverse of SNR}) * 2 * 100 = \% \text{ of intensity fluctuation that can be detected with a 95\% confidence level}$*

- The rule is based on applying 2 standard deviations to give you 95%
- 20:1 signal to noise will detect a 5% intensity change with 95% confidence
- 10:1 = 20%
- 5:1 = 40%

SNR Calculators – Why are they useful?


- Accuracy of measurements – confidence intervals
- Sample Preservation - If you could reduce your exposure time and achieve the same/similar signal to noise to save your sample, you would
- Speed Increases – If you could reduce your exposure time and achieve the same/similar signal to noise to achieve higher speeds, you would

Perceptions

“I need a High Resolution Digital Camera - what Megapixel cameras do you have?”



high-resolution 3.34 million pixel images



DP70, a 12.5 megapixel cooled digital color camera

Resolution: The Rules

1. Resolution is ultimately dependent on the N.A. of the objective or lens used
 2. Microscope resolution in your camera is dependent solely on the size of the pixel – not the number of pixels
 3. Number of Pixels can affect resolution in non-microscope applications
 4. Dynamic range plays a significant role in resolution
 5. How big a field of view you see is determined by size of the chip
-
1. Colour cameras that use a Bayer Mask are lower resolution than the monochrome equivalent by a factor of 3
 2. DPI is only an output resolution. This number represents the resolution of a printed image

**Resolution is ultimately dependent
on the N.A. of the objective.**

Optical Resolution

$$d(\mu\text{m}) = \frac{1.22 * \text{Wavelength } (\mu\text{m})}{\text{NA}_{\text{obj}} + \text{NA}_{\text{Cond}}^*}$$

* Fluorescence use $(2 * \text{NA}_{\text{obj}})$

Fluorescent App: FITC Emission

Example 1: Plan Apo 60x oil (NA 1.4)

$$d(\mu\text{m}) = \frac{1.22 * .510}{1.4 + 1.4} = 0.22 \mu\text{m}$$

Example 2: Plan Fluor 10x dry (NA 0.3)

$$d(\mu\text{m}) = \frac{1.22 * .510}{0.3 + 0.3} = 1.037 \mu\text{m}$$

**We know what our optics can
resolve - can our detector pick it up?**

**Remember: Resolution in your camera is dependent solely
on the size of the pixel**

Our resolving tools

- CCD Chips:

- Sony ICX282AQ - 3.4 μm pixels, 9.74 mm x 7.9 mm imaging
- Sony ICX-205AL – 4.5 μm pixels, 6.5 x 4.8 mm imaging area
- Sony ICX-285 - 6.45 μm pixels, 8.77 x 6.6 mm imaging area
- Kodak KA4021 - 7.9 μm pixels, 16.67mm x 16.05mm imaging area
- CCD97 16 μm – E2V EMCCD sensor

Magnification Factor

- How big is our pixel in the Object space?

Calibrated pixel size = Pixel size / Total Magnification


Easy Maths: 60x objective, Sony 285 sensor

Calibrated pixel size = $6.45 \mu\text{m} / 60\text{x} = \mathbf{0.1075 \mu\text{m/ pixel}}$

We know our smallest object size in our image plane (the specimen), we know the pixel size of our CCD...

What next?

Sampling Requirements



Does our Camera match the Resolving power of our 60x 1.4 NA objective?

Rayleigh Criterion: Plan Apo 60x oil (NA 1.4) = $0.22 \mu\text{m}$

Nyquist: requires a sampling interval equal to twice the highest specimen spatial frequency

Pixel size in Object Space = $6.45 \mu\text{m} / 60\times = 0.1075 \mu\text{m}/\text{pixel}$

Quick Calculation

$$\text{Pixel Size} / \text{Objective Power} \times 2.3 = \text{Resolution}$$

At 10x what size pixel do we need to resolve?

1. Optical Resolution:

Example 2: Plan Fluor 10x dry (NA 0.3)

$$d(\mu\text{m}) = \frac{1.22 * .510}{0.3 + 0.3} = 1.037 \mu\text{m}$$

2. Size of the object on the face of the CCD

$$\text{Object size} = 1.037 * 10 = 10.037 \mu\text{m}$$

3. Nyquist Sampling frequency:

$$10.037 / 2.3 = 4.36 \mu\text{m} = \text{Pixel size to Resolve object}$$


Pixel Size Requirements for Matching Microscope Optical Resolution

Objective (Numerical Aperture)	Resolution Limit (Micrometers)	Projected Size (Micrometers)	Required Pixel Size (Micrometers)
1x (0.04)	6.9	6.9	3.5
2x (0.06)	4.6	9.2	4.6
2x (0.10)	2.8	5.6	2.8
4x (0.10)	2.8	11.2	5.6
4x (0.12)	2.3	9.2	4.6
4x (0.20)	1.4	5.6	2.8
10x (0.25)	1.1	11.0	5.5
10x (0.30)	0.92	9.2	4.6
10x (0.45)	0.61	6.1	3.0
20x (0.40)	0.69	13.8	6.9
20x (0.50)	0.55	11.0	5.5
20x (0.75)	0.37	7.4	3.7
40x (0.65)	0.42	16.8	8.4
40x (0.75)	0.37	14.8	7.4
40x (0.95)	0.29	11.6	5.8
40x (1.00)	0.28	11.2	5.6
40x (1.30)	0.21	8.4	4.2
60x (0.80)	0.34	20.4	10.2
60x (0.85)	0.32	19.2	9.6
60x (0.95)	0.29	17.4	8.7
60x (1.40)	0.20	12.0	6.0
100x (0.90)	0.31	31.0	15.5
100x (1.25)	0.22	22.0	11.0
100x (1.30)	0.21	21.0	10.5
100x (1.40)	0.20	20.0	10.0

Recap

- Lens resolution = $(1.22 * \text{wavelength}) / 2\text{NA}$
- Camera resolution = $\text{Pixel Size} / \text{Objective} * 2.3$
- Appropriate Pixel size = $(\text{resolution (um)} * \text{total magnification}) / 2.3$

Camera Field of View – 1x C-mount



Gain is not Evil

- Gain is a camera control – it's not evil and if used correctly can aid imaging, achieving lower exposure times
- This allows users to see signal in real time or minimise exposure
- Gain does kill dynamic range so it is not exactly angelic




Gain

- Gain is a way of amplifying signal relative to the image scale allowing users to lower the exposure time to achieve the same grey scale values
- Gain really can be thought of as electrons per ADU
- ADU = grey scale value
- Gain is thought to increase noise - this is not necessarily true as noise does not really change, but the grey scales which represent it do increase

Increasing gain effectively lowers dynamic range

What is actually happening at each Pixel?



- System Gain = Single Pixel Full Well (e^-) / Bit Depth (ADU)

Single Pixel Full Well = 16,000 e^-

System Gain = 16,000 e^- / 4,095 ADU

A/D Converter Bit Depth = 4,095


*1x Gain = 4 e^- / ADU
using 12 bit A/D*

*What would it be for
a 14 bit camera?*

Full Well = 16,000 e⁻

4 electrons = 1 ADU


A/D Converter Bit Depth = 4,095



1x Gain = 4e⁻ /ADU



Full Well = 16,000 e⁻




This 4e⁻:1ADU ratio continues until both the CCD Full Well and the A/D converter are filled completely and at the same time.

A/D Converter Bit Depth = 4,095

1x Gain = 4e⁻ /ADU



Full Well = 16,000 e⁻




When the CCD and A/D are full, the system has reached Full Well and the A/D limit.

A/D Converter Bit Depth = 4,095

1x Gain = 4e⁻ /ADU



4x User Gain



4x gain effectively lowers the full well of the CCD by 1/4. In this example, the CCD's effective full well is now 4,000 electrons.

$$\begin{aligned} 4x \text{ single pixel Full Well} &= 1x \text{ single pixel Full Well} / 4 \\ &= 16,000e^- / 4 \\ &= 4,000e^- \end{aligned}$$

A/D Converter Bit Depth = 4,095

$$4x \text{ Gain} = 1e^-/\text{ADU}$$



4x User Gain

Full Well = 4,000e⁻



Now, at 4x gain, 1 electron will produce 1 ADU.

A/D Converter Bit Depth = 4,095

4x Gain = 1e⁻/ADU



4x User Gain

Full Well = 4,000e⁻



This 1e⁻:1ADU ratio continues until the A/D converter has reached its limit.

A/D Converter Bit Depth = 4,095


4x Gain = 1e⁻/ADU



Measuring Gain - Mean Variance

- The mean-variance test is an experimental way to determine the gain
- The premise of this test is rather simple: if the amount of light (electrons) going into the camera is linearly increased, is the response of the camera (ADUs) also linear?
- With a linear response it becomes apparent that a constant gain value is being applied by the camera. If the response of the camera starts becoming non-linear, then all the measurements in the non-linear region cannot be accurately quantified

Mean Variance Calculator



The image shows a screenshot of the Photometrics Mean Variance Calculator interface. It features a dark background with white text and input fields. The Photometrics logo is at the top. Below it, the title 'Single-Point Mean Variance (Gain) Calculator' is displayed. The interface contains several input fields for bias and acquisition data, followed by calculated gain values for bias and acquisition. A 'CALCULATE' button is at the bottom.

Input	Value
Mean of Bias 1:	195.99
Mean of Bias 2:	195.87
Standard Deviation of Bias Diff Image:	25.65
Mean of Acquisition 1:	770.8
Mean of Acquisition 2:	818
Standard Deviation of Acquisition Diff Image:	77
Gain of Bias (e/ADU):	0.5956
Gain of Acquisition (e/ADU):	0.3014

Input fields in white, hit calculate!

Well Depth and Dynamic Range

Well Depth / Full Well Capacity

- Well Depth defines the number of electrons we can hold in the well
- Well Depth drives image quality allowing you to capture both bright and dark images at the same time in neighbouring pixels
- Consider the QICAM 10,000 e and the Retiga 2000R 40,000 e

Usable Dynamic Range

- Dynamic Range is quoted as Full Well/Read Noise
- This gives us the number of statistically measureable points
- QICAM $10,000/12 = 833$
- Exi $16,000/5 = 3200$


Usable dynamic range

- Every CCD placed in a camera has what is called a Full-Well Capacity. This full-well capacity defines the number of electrons that each pixel can detect
- In an ideal world, each electron detected would be translated into the image; however, in real world applications, we have to deal with the effects of noise
- Read noise is a measurement of the noise generated by the camera electronics while reading the electron levels in a CCD. In essence, read noise is the minimum number of electrons that can be detected at any point from the CCD.
- How does this affect the dynamic range?
- Let's say a CCD has a full-well capacity of 1000 electrons per pixel, and the read noise is 50 electrons. Since the minimum number of electrons you can detect at any point is 50, you will only be able to detect 20 discrete levels of signal, resulting in a dynamic range of 20:1.

Useable Dynamic Range

- CoolSnap HQ2 has 16000 electrons in gain 1x = read noise is 5 = Dynamic range 3333:1
- CoolSnap HQ2 has 4000 electrons in 4x gain = read noise is 5 = 800:1
- CoolSnap HQ2 has 32,000 electrons in bin 2x = read noise = 5 = 6400

Dynamic Range Calculator



The image shows a screenshot of the Photometrics Dynamic Range Calculator. It features a dark blue header with the Photometrics logo and name. Below the header, the title 'Dynamic Range Calculator' is centered. There are three input fields: 'Full Well Capacity' with the value '400000', 'Read Noise' with the value '25', and 'Dynamic Range' with the value '16000'. The 'Dynamic Range' field is highlighted with a grey background and includes a ': 1' suffix. A 'CALCULATE' button is located at the bottom of the calculator interface.

Parameter	Value
Full Well Capacity	400000
Read Noise	25
Dynamic Range	16000 : 1

Input fields in white, hit calculate!

Changing gain to match grey scale – effect on dynamic range

CoolSnap Gain 1 (1e/ADU)

1 second exposure – Mean 2000 grey scales

Signal = 2000 electrons

Noise 45 electrons = 45 greyscales

$S/N = 2000/45 = 44:1$

Well Depth 16,000

Dynamic Range $16000:45 = 3333:1$

CoolSnap Gain 4x (0.25e/ADU)

250ms exposure – Mean 2000 grey scales

Signal = 500 electrons

Noise = 23 electrons = 92 greyscales

$S/N = 500/22 = 25:1$

Well Depth 4,000


Dynamic Range $4000:5 = 800:1$

What gain should I use?


- **Gain 1x** – This should be designed by the engineer to give you the highest number of discernable grey levels = Largest Dynamic Range
- **Higher than 1x Gain** – this can be used to achieve a visible signal earlier (please note the camera is not more sensitive to light at this point)
- **Lower than 1x Gain** – this should be used when the camera is set to binning mode to enable high dynamic range

Using lower than 1x

- Pre digitisation the electronic charge is held in the output node
- When binning, the output node must now accommodate more charge than the linear full well of a sensor
- In such occasions the AD, which was set previously to match the full well, is no longer maximising dynamic range
- By lowering the gain we maximise our sensor for dynamic range in a binned state




Binning




- Higher Dynamic Range
- Higher Signal-to-Noise Ratio
- Faster Readout
- Dynamically Change Pixel Size/Aspect Ratio

Above all gained at the expense of Spatial Resolution!!


CCD Fundamentals




CCD Fundamentals




CCD Fundamentals




CCD Fundamentals




CCD Fundamentals




CCD Fundamentals




CCD Fundamentals



CCD Fundamentals



CCD Fundamentals



THE END

Thanks for listening